

**Condensing Heat Exchanger Kit  
For use with 35-in. (889 mm)  
High Efficiency Gas Furnace**

## Installation Instructions

**NOTE:** Read the entire instruction manual before starting the installation.

### **REPLACEMENT CONDENSING HEAT EXCHANGER KIT NUMBERS**


1184345 - 1184347, 1184396, 1184780 - 1184782, 1185449 - 1185456,  
1185896 - 1185897, 1186793 - 1186799

### **SAFETY CONSIDERATION**

Improper installation, adjustment, alteration, service, maintenance, or use can cause explosion, fire, electrical shock, or other conditions which may cause death, personal injury, or property damage. Consult a qualified installer, service agency, or your distributor or branch for information or assistance. The qualified installer or agency must use factory-authorized kits or accessories when modifying this product. Refer to the individual instructions packaged with the kits or accessories when installing.

Follow all safety codes. Wear safety glasses, protective clothing, and work gloves. Have a fire extinguisher available. Read these instructions thoroughly and follow all warnings or cautions included in literature and attached to the unit. Consult local building codes, the current editions of the National Fuel Gas Code (NFGC) NFPA 54/ANSI Z223.1 and the National Electrical Code (NEC) NFPA 70.

In Canada, refer to the current editions of the National Standards of Canada CAN/CSA-B149.1 and .2 Natural Gas and Propane Installation Codes, and Canadian Electrical Code CSA C22.1.

Recognize safety information. This is the safety-alert symbol . When you see this symbol on the unit and in instructions or manuals, be alert to the potential for personal injury.

Understand the signal words DANGER, WARNING, and CAUTION. These words are used with the safety-alert symbol. DANGER identifies the most serious hazards which will result in severe personal injury or death. WARNING signifies hazards which could result in personal injury or death. CAUTION is used to identify unsafe practices which may result in minor personal injury or product and property damage. NOTE is used to highlight suggestions which will result in enhanced installation, reliability, or operation.

### **WARNING**

#### **FIRE, EXPLOSION, ELECTRICAL SHOCK HAZARD**

Failure to follow this warning could result in personal injury, death and/or property damage.

The ability to properly perform maintenance on this equipment requires certain knowledge, mechanical skills, tools, and equipment. If you do not possess these, do not attempt to perform any maintenance on this equipment other than those procedures recommended in the User's Manual.

### **WARNING**

#### **FIRE, EXPLOSION, ELECTRICAL SHOCK AND CARBON MONOXIDE POISONING HAZARD**

Failure to follow this warning could result in personal injury, death and/or property damage.

Improper installation, adjustment, alteration, service, maintenance, or use can cause carbon monoxide poisoning, explosion, fire, electrical shock, other conditions, which could result in personal injury or death. Consult your distributor or branch for information or assistance. The qualified installer or agency must use only factory-authorized kits or accessories when servicing this product.

### **WARNING**

#### **ELECTRICAL SHOCK, FIRE OR EXPLOSION HAZARD**

Failure to follow this warning could result in personal injury or death, or property damage.

Before installing, modifying, or servicing system, main electrical disconnect switch must be in the OFF position and install a lockout tag. Check accessories and cooling unit for additional electrical supplies that must be shut off during the furnace servicing. There may be more than one disconnect switch. Lock out and tag switch with a suitable warning label. Verify proper operation after servicing.

### **CAUTION**

#### **CUT HAZARD**

Failure to follow this caution may result in personal injury.

Sheet metal parts may have sharp edges or burrs. Use care and wear appropriate protective clothing and gloves when handling parts

## **INTRODUCTION**

This instruction covers installation of the Condensing Heat Exchanger Kit, Part No. 1184345 thru 1184347, 1184396, 1184780 thru 1184782, 1185449 thru 1185456, 1185896, 1185897, 1186793 thru 1186799 in 35-in. (889 mm) tall, condensing gas furnaces.

There are two different RTV sealants used on this assembly and are needed before starting the assembly.

The low adhesion sealant used on the Condensing Heat Exchanger Kit is Novaguard RTV 400-900 (Part Number 1185242). If the high adhesion sealant is used, also use a releasing agent such as cooking spray (must not contain corn oil, canola oil, halogenated hydrocarbons nor aromatic contents to prevent inadequate seal from occurring). Novaguard 400-303 RTV (Part Number 1185241), G.E. 162, G.E. 6702, or Dow-Corning 738 are approved high adhesion silicone.

**NOTE:** DO NOT use a releasing agent on parts that will be sealed with RTV.

**NOTE:** DO NOT substitute any other type of RTV sealant.

## DESCRIPTION AND USAGE

Use this Condensing Heat Exchanger kit to replace a failed Condensing Heat Exchanger. This Condensing Heat Exchanger Kit contains the following items, see [Table 1](#) for kit contents.

**Table 1 – Kit Contents**

Description	Quantity
HX & Panel Assy.	1
Containment Plate	1
Screw	2 Bags
Gasket	2
Coll. Box Gasket	1
Instructions	1

## INSTALLATION

### Unit Shut Down

1. Set room thermostat to lowest setting or “OFF.”
2. Disconnect power at external disconnect, fuse or circuit breaker.
3. Turn off gas at external shut-off or gas meter.
4. Remove outer doors and set aside.
5. Turn electric switch on gas valve to OFF.

### Vent Pipe Removal

**NOTE:** It will be necessary to remove the vent pipe from the furnace in order to remove the Heat Exchanger.

1. Support the vent pipe as close to the furnace as possible to prevent damage to the vent system.
2. Cut vent pipe with a hacksaw and move the remaining vent pipe out of the way. Secure the vent pipe if necessary.
3. Loosen both clamps at the vent pipe support attached to furnace casing.
4. Loosen clamp for the vent pipe at vent elbow on the inducer assembly.
5. Remove remaining vent pipe through the top of the furnace casing and set aside.

### Manifold Removal / Burner Box Removal

**NOTE:** Use a back-up wrench on the gas valve to prevent the valve from rotating on the manifold or damaging the mounting to the burner box, see [Fig. 3](#).

1. Disconnect the gas pipe from gas valve and remove pipe from the furnace casing.
2. Disconnect the connector harness from gas valve (Modulating only) or remove individual wires from terminals on gas valve (All other models).
3. Disconnect the wires from gas valve, flame sensor and hot surface igniter.
4. Remove wires from both rollout switches.



**CAUTION**

#### UNIT OPERATION HAZARD

Failure to follow this caution may result in improper furnace operation or failure of furnace.

Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation.

5. Support the manifold and remove the 4 screws that secure the manifold assembly to the burner box and set aside. Note the location of the green and yellow ground wire for reassembly later.
6. Support the burner box assembly and remove the screws that attach the burner box to the Heat Exchanger Cell Panel.
7. Set the burner box assembly aside.

### Pressure Switch Removal

**NOTE:** There are two types of pressure switches. The modulating pressure switch assembly has three pressure switches. Two are side-by-side with the third switch mounted to the back of one of the switches.

All other furnaces have two pressure switches mounted back-to-back.

The tube for the front pressure switch connects the switch to the port on the Collector Box. For PSC inducers only, the tube for the switch mounted on the back connects the switch to the port on the inducer assembly.

1. Remove the front pressure switch tube from the port on the Collector Box, see [Fig. 3](#).
2. Disconnect the pressure switch harness (modulating only) from the main wiring harness or remove the individual wires from the front pressure switch (non-modulating). Note the location of the wires for reassembly.



**CAUTION**

#### UNIT OPERATION HAZARD

Failure to follow this caution may result in improper furnace operation or failure of furnace.

Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation.

3. Remove the screws that attach the pressure switch assembly to the inducer.
4. Remove the back pressure switch tube that connects to the inducer assembly.
5. Remove the wires from the back pressure switch. Note the location of the wires for reassembly. (PSC only).
6. If the relief tube for the Condensate Trap is routed across the inducer assembly, remove the tube from the port on the Collector Box and from the stand-offs on the inducer and move the tube aside.
7. Set the pressure switches aside.

### Inducer Assembly Removal

**NOTE:** See [Fig. 3](#) for inducer assembly detail and component locations.

1. Remove the door bracket from the front edge of the blower shelf.
2. Remove the wires that connect the main wiring harness to the inducer motor harness.
3. Remove the Condensate Trap relief tube from the port on the Collector Box and the stand-offs on the inducer housing.
4. Remove the screws from the tabs on inducer assembly that secures the inducer to the Collector Box.

**NOTE:** There is one mounting tab directly under the vent elbow.

5. Remove the inducer assembly and set aside.
6. To avoid double gasketing and leakage, check to make sure the drain gaskets for the inducer and the inducer inlet gasket are not still attached to the Collector Box.
7. Remove any adhered gaskets from the front of the Collector Box. Verify old gaskets are re-usable or obtain new gaskets from the distributor. Apply gaskets to the rear of the inducer housing and set aside for reassembly later.

### Condensate Drain and Trap Removal

**NOTE:** If the Condensate Trap is removed, a new gasket between the trap and Collector Box is required. Obtain one from your local distributor, see [Fig. 1](#) and [Fig. 3](#).

1. Disconnect external drain from condensate drain elbow or drain extension pipe inside the furnace and set aside.

2. Disconnect the Condensate Trap relief hose from Collector Box port and the molded retainer clips on the inducer housing.

**NOTE:** If condensate has a heat pad attached to the trap, trace the wires for the pad back to the connection point and disconnect the wires for the heat pad.

3. Remove the screw that secures the Condensate Trap to the Collector Box, remove the trap and set aside.
4. Rinse Condensate Trap in warm water until trap is clean.
5. Clean relief port on Condensate Trap with a thin wire or paper clip, rinse with warm water and set aside.
6. Flush condensate lines with warm water.
7. Shake trap dry.

### Remove J-Box and Main Harness

1. Remove the screw that secures the J-Box cover to the J-Box bracket, see Fig. 2.
2. Disconnect the field wiring from the factory wiring and remove the ground wire from the green ground screw on the J-Box bracket.
3. Remove factory wiring from the J-Box.
4. Disconnect the factory wires from the main limit switch.
5. Remove the screw that secures the door switch to the blower shelf and the blower shelf door bracket. Remove the screws from the blower shelf door bracket, and set the bracket aside.
6. Remove main harness from the slot in the blower shelf.

### Collector Box Removal

1. Remove the screws that secure the Collector Box to the Heat Exchanger Cell Panel and set aside.
2. Remove Collector Box gasket and discard.
3. Flush out the Collector Box with warm water including the tube ports. Clean tube ports on Collector Box with a thin wire or paper clip, rinse with warm water and set aside.

### Heat Exchanger Assembly Removal



#### CUT HAZARD

Failure to follow this caution may result in personal injury. Sheet metal parts may have sharp edges or burrs. Use care and wear appropriate protective clothing and gloves when handling parts and servicing furnaces.

1. Remove the screws that attach the filler plate to the bottom edge of the Condensing Heat Exchanger Assembly and casing.
2. Remove screws that secure the Heat Exchanger Assembly to the furnace casing. Do not remove the screws around the burner inlets that attaches the primary inlet panel to the inlet plate of the Primary Heat Exchanger.
3. Pull assembly out of casing until the back edge of the Heat Exchanger is resting on the front edge of the blower shelf.
4. Lift the Heat Exchanger Assembly out of the casing and set aside.

### Remove Coupling Box

1. Remove the screws that secure the finger baffle from the Coupling Box Cover, see Fig. 5.
2. Remove the screws that secure the Coupling Box Cover to the rear of the Heat Exchanger Assembly.
3. Starting at the upper beveled edge of the Coupling Box, use a putty knife or gasket scraper to get between the Coupling Box Cover and the Primary Cell Outlet panel to break the silicone seal between the parts.

4. Pry upwards with the putty knife as you move around the Coupling Box Cover.
5. Once the Coupling Box Cover is sufficiently loosened, remove the Coupling Box Cover from the rear of the Heat Exchanger Assembly, see Fig. 4.

### Separate Primary and Condensing Heat Exchangers

1. Remove the screws that attach the Condensing Heat Exchanger Assembly to the Primary Cell Outlet Panel and remove the screws that attach the Condensing Heat Exchanger Outlet Panel to the Primary Inlet Panel.
2. Gently use a putty knife or gasket scraper to get between the Primary Cell Inlet Panel and Condensing Heat Exchanger if it is needed to break the seal between the parts.
3. Repeat the procedure at the Primary Cell Outlet Panel and containment plate attached to the inlet of the Secondary Heat Exchanger.

### Remove Primary and Condensing Heat Exchanger

**NOTE:** The Primary Heat Exchanger Assembly is factory- assembled at Primary Cell Attachment Plate and the Primary Rear Cell Outlet Panel. The individual Heat Exchanger cells cannot be removed in the field and are replaced as one assembly.

1. Remove screws that attach the sidewall baffles to the Heat Exchanger Cell Panel, see Fig. 6.

**NOTE:** The front edge of the sidewall baffle has a slot that engages a tab on the Primary Cell Panel, see Fig. 6.

2. Avoid damaging the cell panel insulation by pulling the sidewall baffle outward from the rear of Coupling Box, then pull the baffle backward to slide the baffle off of the locator tab on the cell panel.
3. Repeat the procedure for the opposite side baffle.
4. Separate the Primary Heat Exchanger from the Condensing Heat Exchanger.
5. Discard failed Condensing Heat Exchanger Assembly.

### Turbulator Removal

**NOTE:** The turbulators are factory-installed in a replacement Condensing Heat Exchanger. It is not necessary to remove them to replace a condensing Heat Exchanger Assembly. If it is necessary to remove the turbulators, perform the following steps:

1. Bend the end of turbulator strip that holds it inside the Secondary Heat Exchanger tube straight.

**NOTE:** Use caution when removing the turbulator strips. Do not bend, twist kink or flatten the turbulator strip. A damaged turbulator strip must be replaced with the identical type of turbulator strip used with the furnace. Do not use a turbulator strip from a different model family of furnaces. Efficiency, reliability or unit operation may be affected.

2. Pull the turbulator strip outward from the tube.
3. Repeat the step for each turbulator.
4. Wipe each turbulator off with a clean, soft cloth.

### BEGIN RE-ASSEMBLY

#### Turbulator Installation

**NOTE:** The turbulators are factory-installed in a replacement condensing Heat Exchanger. If the turbulators were removed for cleaning, re-install the turbulators as follows:

1. Make sure that one end to the turbulator strip is bent 90 degrees.

**NOTE:** Use caution when installing the turbulator strips. Do not bend, twist kink or flatten the turbulator strip. A damaged turbulator strip must be replaced with the identical type of turbulator strip used with the furnace. Do not use a turbulator strip from a different model family of furnaces. Efficiency, reliability or unit operation may be affected.

2. Push the straight end of turbulator strip forward into the Secondary Heat Exchanger tube until the angled end is against the edge of the tube.
3. Repeat the step for each turbulator.
4. Bend the straight end of the turbulator strip over 90 degrees to hold the turbulator in the Secondary Heat Exchanger tube.

### Install Containment Plate

**NOTE:** Both the containment plate and Secondary Heat Exchanger panel surfaces must be clean and dry. All loose or residual sealant must be removed from the mating surfaces.

**NOTE:** Do not use a releasing agent on the Containment Plate or Heat Exchanger Assembly.

1. Apply a 3/16" wide bead of high adhesion (grey) silicone, Novaguard 400-303 RTV, or equivalent as noted on page 1, around the Containment Plate as shown in Fig. 7. Note the orientation of the plate in Fig. 7.
2. Align the containment plate as shown in Fig. 7.
3. Temporarily hold the containment plate in place by installing one screw through the hole on each side of the containment plate.

**NOTE:** After the Primary Heat Exchanger Assembly is attached to the Secondary Heat Exchanger, these screws will be removed to allow the Coupling Box Cover to be installed.

### Attaching Primary and Condensing Heat Exchangers

1. Align the bottom edge primary cell outlet panel with the top edge of the Condensing Heat Exchanger Assembly, and align the top edge of the Condensing Heat Exchanger outlet panel with the bottom edge of the primary cell inlet panel.
2. The orange foam gasket must be between the primary cell outlet panel and the containment plate that is temporarily attached to the Condensing Heat Exchanger. The white fiber gasket or equivalent must be between the primary cell inlet panel and the Condensing Heat Exchanger outlet panel.
3. Insert all the screws, except the outboard screws in the primary outlet panel, to secure the Primary Heat Exchanger panels to the Condensing Heat Exchanger panels (front and back), see Fig. 5.
4. Remove the screws used to temporarily hold the Containment Plate in place.

### Install Coupling Box Cover/Finger Baffles

1. Apply a 1/4" bead of low adhesion silicone (white) to the Coupling Box Cover in the pattern shown in Fig. 7.
2. Align the Coupling Box Cover over the rear of the Heat Exchanger Assembly, see Fig. 5 and Fig. 4.
3. Install the screws that secure the bottom edge and sides of the Coupling Box to the Heat Exchanger Assembly.
4. Align the Finger Baffles along the top edge of the Coupling Box Cover, see Fig. 5.
5. Install the screws for the Finger Baffles and the remaining screws for the top edge of the Coupling Box Cover.
6. Align the sidewall baffles to the Heat Exchanger Cell Panel, see Fig. 4 and Fig. 6.

**NOTE:** The front edge of the sidewall baffle has a slot that engages a tab on the primary cell panel.

7. Avoid damaging the cell panel insulation by inserting the sidewall baffle inward from the rear of coupling box to the indexing tab on the Primary Cell Panel, then align the baffle with the Coupling Box Cover.
8. Secure the Sidewall Baffles with the screws.

### Install Sidewall Baffles

1. Insert the slot on the sidewall baffle over the tab on the primary cell panel, see Fig. 6.
2. Insert the screws that attach the sidewall baffle to the primary cell panel.
3. Align the rear edge of the baffle with the screw holes in the Coupling Box Cover.
4. Insert the screws that attach the sidewall baffles to the coupling box.

### Heat Exchanger Assembly Installation

1. Lift the Heat Exchanger Assembly and set the rear of the assembly on the blower deck.
2. Slide the Heat Exchanger onto the support rails in the furnace casing.
3. Raise the rear of the Heat Exchanger and set the bottom of the sidewall baffles on top of the support rails in the blower deck.
4. Slide the Heat Exchanger Assembly into the casing, making sure the bottom edge of the sidewall baffle slides into the engagement tab on the support rails.

**NOTE:** Be sure cell panel insulation is folded over the top flange of the primary cell inlet panel so that when the Heat Exchanger is fully installed, the insulation seals between the top plate and the top flange of the cell panel.

**NOTE:** Be sure the cell panel insulation is visible on both sides of the Heat Exchanger Cell Panel so that when the Heat Exchanger is fully installed, the insulation seals between the cell panel and the mounting brackets. If any insulation is not visible, pull the Heat Exchanger forward, adjust the insulation and reinstall so that the cell panel is properly sealed to the top plate and to the mounting brackets.

5. Continue to slide the Heat Exchanger Assembly backward into the casing until the primary cell panel is flush with the mounting brackets on the side of the casing.
6. Align the primary cell panel with the mounting brackets.
7. Insert the screws that attach the primary cell panel to mounting brackets on the casing.
8. Align the filler plate to the bottom edge of the Condensing Heat Exchanger Assembly.
9. Secure the filler plate to the Condensing Heat Exchanger and casing.

### Collector Box Installation

1. Verify old Collector Box gasket is reusable or obtain a new gasket from the distributor (preferred).
2. Obtain new Condensate Trap gasket from distributor and install.

**NOTE:** There is a slot on each side of the front panel of the Condensing Heat Exchanger. The Collector Box has alignment tabs on the back that fit into the slots on the Condensing Heat Exchanger panel.

3. Align the tabs on the Collector Box to the slots on the Condensing Heat Exchanger panel.
4. With the Collector Box fully seated against the Condensing Heat Exchanger Cell Panel, install the screws through the Collector Box.
5. Tighten the screws in an alternating pattern around the Collector Box to 21 lb-in. Do not over-tighten.

### Install J-Box and Main Harness

1. Insert grommet for main harness in the slot in the blower shelf.
2. Align the door switch to the blower shelf.
3. Align and install door bracket to the front edge of the blower shelf and secure the door switch during upper door bracket installation.
4. Connect the field wiring from the factory wiring and attach the ground wire to the green ground screw on the J-Box bracket.

5. Attach the J-Box cover to the J-Box bracket.
6. Install the screw to secure the J-Box cover to the bracket.
7. Connect the factory wires to the main limit switch.

### Install the Condensate Trap and Drain

**NOTE:** If the Condensate Trap is removed, a new gasket between the trap and Collector Box is required. Obtain one from your local distributor.

1. Align the trap with the drain outlet on the Collector Box.
2. Secure the trap to the Collector Box with the screw.
3. Connect the Condensate Trap relief tube from Collector Box port and insert the tube into the molded retainer clips on the inducer housing.
4. Insert the condensate drain elbow through the casing until it is properly seated. Or, connect the drain elbow to the drain extension pipe and route the pipe behind the inducer.
5. Connect the drain elbow to the Condensate Trap.

**NOTE:** If condensate has a heat pad attached to the trap, trace the wires for the pad back to the connection point and connect the wires for the heat pad.

### Inducer Assembly Installation

1. Verify any remaining gaskets on the front of the Collector Box are removed.
2. Verify the inducer assembly has gaskets on the drain stubs and at the inducer inlet.
3. Verify the choke plate is installed on the inlet opening of the inducer.
4. Align the tabs on inducer assembly to the brass inserts on the Collector Box.
5. Insert the mounting screws through the tabs to secure the inducer to the Collector Box. Remember there is a mounting tab located under the vent elbow.
6. Connect the inducer leads from the main wiring harness to the inducer motor harness.

### Pressure Switch Installation

**NOTE:** There are two types of pressure switches. The modulating pressure switch assembly has three pressure switches.

Two are side-by-side with the third switch mounted to the back of one of the switches.

All other furnaces have two pressure switches mounted back-to-back.

The tube for the front pressure switch connects the switch to the port on the Collector Box. The tube for the switch mounted on the back connects the switch to the port on the inducer assembly.

1. Connect the wires to the back pressure switch.
2. Connect the tube for the back pressure switch to the inducer assembly.
3. Connect the tube for the front pressure switch to the port on the Collector Box.
4. Attach the pressure switch assembly to the inducer.
5. Connect the pressure switch harness (modulating only) to the main wiring harness or attach the individual wires to the pressure switch (non-modulating).
6. If necessary, route the pressure switch tubing for the front pressure switch through the stand-off on the inducer assembly.
7. If necessary, route the Condensate Trap relief tubing through the stand-off on the inducer assembly. Reconnect tubing to the ports on the Condensate Trap and Collector Box.

### Burner Box/Manifold Installation

1. Support the burner box assembly and install the screws that attach the burner box to the Heat Exchanger Cell Panel.

2. Align the orifices in the manifold assembly with the support rings on the end of the burner.
3. Insert the orifices in the support rings of the burners. Manifold mounting tabs should fit flush against the burner box

**NOTE:** If manifold does not fit flush against the burner box, the burners are not fully seated forward. Remove the manifold and check burner positioning in the burner box assembly.

4. Attach the green/yellow wire and ground terminal to one of the manifold mounting screws.
5. Install the remaining manifold mounting screws.
6. Connect the wires to both rollout switches.
7. Connect the wires to the flame sensor and hot surface igniter.
8. Connect the connector harness from gas valve (Modulating only) or attach the individual wires to the terminals on gas valve (All other models).

**NOTE:** Use only propane-resistant pipe dope. Do not use Teflon tape.

9. Insert the gas pipe through the grommet in the casing. Apply a thin layer of pipe dope to the threads of the pipe and thread the pipe into the gas valve.

**NOTE:** Use a back-up wrench on the gas valve to prevent the valve from rotating on the manifold or damaging the mounting to the burner box.

10. With a back-up wrench on the inlet boss of the gas valve, finish tightening the gas pipe to the gas valve.
11. Turn gas on at electric switch on gas valve.
12. Turn power on at external disconnect, fuse or circuit breaker.

### Vent Pipe Installation

1. Insert the vent pipe through the intended vent opening of the furnace casing and insert into the outlet of the inducer vent elbow.
2. Tighten the clamp for the vent pipe at vent elbow on the inducer assembly.
3. Align the remaining vent pipe system to the vent pipe in the furnace casing.
4. Solvent cement the pipes as required for the type of material used.
5. Tighten both clamps at the vent pipe support attached to furnace casing.

### Unit Checkout



#### **FIRE OR EXPLOSION HAZARD**

Failure to follow this warning could result in personal injury, death and/or property damage.

Never purge a gas line into a combustion chamber. Never test for gas leaks with an open flame. Use a commercially available soap solution made specifically for the detection of leaks to check all connections. A fire or explosion may result causing property damage, personal injury or loss of life.

1. Set thermostat to "OFF".
2. Turn on power at external disconnect, fuse or circuit breaker.
3. Turn on gas at external shut-off or gas meter.
4. Check for gas leaks with a commercially available soap solution made specifically for the detection of leaks.
5. Manually close blower door switch.

# ! WARNING

## ELECTRICAL OPERATION HAZARD

Failure to follow this warning could result in personal injury or death. Blower door switch opens 115-v power to control. No component operation can occur unless switch is closed. Caution must be taken when manually closing this switch for service purposes.

6. Initiate component test through circuit board by referring to "Component Test" on status code label on blower access door for complete test sequence information.
7. If any status codes are flashed, refer to status code label on unit blower door.
8. Turn thermostat fan switch to "ON", "Continuous" or jumper R to G terminals at furnace control board.
9. Check for air leakage around cell panel. It may be necessary to remove Heat Exchanger Assembly and top gasket between cell panel and furnace casing top plate. Re-install and re-check for blower air leaks.
10. Remove jumper(s) or set thermostat fan to "Auto" or "OFF".
11. Release blower door switch.
12. Install blower access door.
13. Set thermostat to call for heat.
14. Allow unit to initiate a complete call for heat cycle.

15. Check for air leakage around Collector Box. A whistling noise may indicate air leak in Collector Box seal.

**NOTE:** If there is a severe air leak in the Collector Box seal, pressure switch may not close or will re-open, resulting in no ignition or erratic burner operation.

**NOTE:** Heat Exchanger failure may have been caused by one or more of the following conditions. As part of the system check-out, verify that the following conditions are not affecting the operation of the furnace:

- Short Cycling-Defective thermostat: Incorrect thermostat anticipator setting, dirty filter or over-sized furnace.
  - Under firing/low Btu input: Set manifold pressure and verify firing rate as shown on rating plate by clocking the gas meter.
  - Over-firing/high Btu input: Set manifold pressure and verify firing rate as shown on rating plate by clocking the gas meter.
  - Low temperature rise: Set unit for correct temperature rise range as shown on unit rating plate.
  - Contaminated combustion air: Remove contaminants or provide ample fresh air for combustion.
  - Excessive amounts of outside ventilation air: Return air temperature cannot be below 60 degrees F for extended periods of time.
  - Incorrect venting or termination: Recirculation of products of combustion into the combustion air pipe can damage the furnace. Verify proper venting and vent termination per installation instructions. For additional information, and a complete sequence of furnace operation, refer to furnace Installation, Start-Up and Operating Instructions.
16. After System Check-out is complete, set thermostat below room temperature.
  17. Verify that burner shuts down and blower completes selected off delay time.
  18. Verify furnace operates properly and set thermostat to desired room temperature.
  19. Re-install outer door.




Fig. 1 – Collector Box Gasket Condensate Trap

A11442





Fig. 3 – Loosen Vent Pipe Clamp

A11361




Fig. 2 – J-Box Removal / Installation

A11299




Fig. 4 – Sidewall Baffle Removal / Installation - Rear View

A11414




Fig. 5 – Condensing Heat Exchanger Removal / Installation

A13103







Fig. 6 – Heat Exchanger Panel Assembly

A11438



**Fig. 7 – Containment Plate and Collector Box Sealant Application**

A11416